

Press release AGRITECHNICA 2025

Textbausteine

REITER today

Reiter - the only real specialist of belt rakes and the technological leader with its flexible Respiro pick-up. 26 employees at two locations, Hofkirchen an der Trattnach (development, sales) and Pichl bei Wels (production) in Upper Austria. Change in ownership structure: Voran Maschinen GmbH is majority owner since November 2024. This empowers the partnership that began in 2018 and secures production capacities for further growth.

The turnover for the financial year 2024 was at €4.2 million. And the incoming orders developed very positively in the first eight months of 2025. In Germany, the sales team is now supported by Christian Markus, in France by the product specialist Claude Bouteraa. Sales markets are in over 30 countries on all continents except South America; the development of new products is being pushed forward in order to better address customer segments.



Christian Markus

T: [+49 151 17661739](tel:+4915117661739)

E: christian.markus@reiter-respiro.com

Sales & promotion

Northern and Eastern Germany and Lower Bavaria



Claude Bouteraa

T: [+33 6 70 91 26 66](tel:+33670912666)

E: claudio.bouteraa@reiter-respiro.com

Product specialist France

RESPIRO technology on the rise thanks to special features

RESPIRO technology on the rise thanks to special features

Excellent ground adaptation for the cleanest forage in any circumstance; the average of direct benefit is about €100.00 /cow & year

Small pick-up with new spoiler design ensures optimal crop flow – gentle on forage

Pure flexibility: 3-50 m onto one swath => optimal size and uniformity

This results in top cutting quality and productivity for all subsequent harvesting machines

Increased harvesting performance – regardless of yield of area

On average, approx. 30% lower harvesting costs of high-performance forage harvesters

Less wear on the cutting units – blades that stay sharp longer deliver consistently top cutting quality

RESPIRO R8 compact – the entry-level model for farmers

The market launch is in full swing; customers appreciate its versatility and flexibility in the field; perfectly smooth running thanks to 4-wheel chassis and flexible pick-up.

Thanks to lightweight construction, it has only 4 650 kg weight, working width of 8 m for middle swath and 6 m plus swath width for side placement. Dimensions for transport: height 3.4 m, width 2.95 m, length 5.6 m; requires 100 HP, has its own oil supply with gear pump for PTO speed 1000/750/540 rpm, best ground adaptation thanks to patented kinematics, adjustment of belt speed from the cab, new pick-up design for optimised crop flow, rotor with central adjustment of the swath roller, belt substructure with new belt tensioning, special folding mechanism, pneumatic brake, required connections Load Sensing and 2 double acting connections

NEW: RESPIRO R10 profi – the Belt Rake for professional farmers, contractors, and large farms

New design, fully ISOBUS-compatible, top working comfort, robust construction, 6,500 kg weight, 10 m working width with middle placement, 7.5 m plus swath width for side placement, transport height 3.95 m, width 2.96 m, length 6.4 m, 4-wheel technology for perfect ground contour following, use in slopes without problems, perfect weight distribution, power requirement from 150 HP, independent oil supply with axial piston pump, PTO 1000 rpm, excellent ground adaptation thanks to sophisticated kinematics, adjustable belt speed from the cab, new conveyor belt for more performance for all kind of crops, small pick-up diameter of 335 mm for optimal crop flow also for small forage quantities and large swaths, requires Load Sensing connections.

Optional:

Central lubrication for maximum comfort

Vertical conveyor belts for perfect swath quality even in the most challenging harvesting conditions

RESPIRO R7 rd / R6 rd – never drive over your forage again

Ideal for farms with reverse-drive tractors, from 175 HP and with front ballast of approx. 800-1,200 kg – never drive over your forage again, perfect view of the working units, as manoeuvrable as a self-propelled machine, no center placement, only side placement of forage left or right, or left and right simultaneously, powered via tractor hydraulics, 160 l/min required, oil cooler, from 2,950 kg – 3,380 kg, working width 6 m or 7 m, belt width 1000 mm, R6 rd also available with 700 mm belt for improved center-of-gravity distance, transport height 3.5 m or 4.0 m, transport width 2.4 m, transport length 2.37 m resp. 2.67 m, parking dimensions 2.4 x 2.67 m – very little space required, patented swath-roller-system for optimal ground adaptation, easy control via terminal.

NEW generation RESPIRO front machines

Compact series redesigned with new pick-up-technology with integrated spoiler, 3 m and 3.5 m working width = transport width, ideal for turning straw swaths and clearing out corners, forage can be transported on the belt, gentle on legumes, ideal for stony fields, ensures the best forage quality; on large fields and under challenging harvesting conditions, the front-mounted machine can be combined with the trailed RESPIRO mergers R10, R9, or R8: no driving over the crop, the swath is perfectly placed, optimal pick-up quality for all subsequent harvesting machines.

These text modules and image materials can be found on the homepage at:

<https://www.reiter-respiro.com/reiter-presse/>

For further questions please contact:

DI Thomas Reiter: T: +43 650 2891965

Thomas Keplinger: T: +43 664 9258914

E: thomas.reiter@reiter-respiro.com

E: thomas.keplinger@reiter-respiro.com